












Maintenance schedule

Maintenance

ITEM	FREQUENCY	Pre-ride check								Remarks	Page			
		500 Km.	1,500 Km.	3,000 Km.	4,500 Km.	6,000 Km.	Every 6 months	Yearly check	Every 2 years					
Spark Plug				I										-
Valve clearance		I		I		I								-
Crankcase breather			C	C	C	C	C	C	C		C			80
Engine oil filter screen		C	C	C	C	C	C	C	C					59
Engine idle speed		I	I	I	I	I	I	I	I		I			-
Radiator coolant		I	I	I	I	I	I	I	I		I		R	64
Cooling system		I	I	I	I	I	I	I	I		I			-
Drive chain slider / tensioner		I	I	I	I	I	I	I	I		I			73
Drive / driven sprocket		I	I	I	I	I	I	I	I		I			46
Drive chain slider		I	I	I	I	I	I	I	I		I			-
Brake system		I	I	I	I	I	I	I	I		I			-
Clutch fluid		I	I	I	I	I	I	I	I		I		R	107
Rear suspension		I	I	I	I	I	I	I	I		I			-
Damper linkage / rods		I	I	I	I	I	I	I	I		I			-
Fork oil													R	-
Steering pipe bearing		I	I	I	I	I	I	I	I		I			-
Wheel bearings				R										-
Nuts, bolts and fasteners		I	I	I	I	I	I	I	I		I			-

Check the item after riding in adverse conditions and dusty areas.

Check the items more often when riding in adverse conditions and dusty areas.