

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.  
Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 36	<b>Crankcase Breather</b> .....	P. 75
<b>Maintenance Schedule</b> .....	P. 38	<b>Other Adjustments</b> .....	P. 76
<b>Maintenance Fundamentals</b> .....	P. 41	Adjusting the Headlight Aim .....	P. 76
<b>Removing &amp; Installing Body Components</b> ..	P. 55		
Battery .....	P. 55		
Seat .....	P. 56		
<b>Spark Plug</b> .....	P. 57		
<b>Engine Oil</b> .....	P. 59		
<b>Air Cleaner</b> .....	P. 62		
<b>Brakes</b> .....	P. 63		
<b>Side Stand</b> .....	P. 66		
<b>Drive Chain</b> .....	P. 67		
<b>Clutch</b> .....	P. 71		
<b>Throttle</b> .....	P. 74		