

Servicing Your Honda

To help keep your Honda MUV in good shape, this section includes a Maintenance Schedule for required service and step-by-step instructions for specific maintenance tasks. You'll also find important safety precautions, information on fuels and oils, and tips for keeping your Honda looking good.

For information about replacing fuses, see page 188.

(USA & Canada only)

For information about the exhaust emission and noise requirements of the U.S. Environmental Protection Agency (EPA), the California Air Resources Board (CARB), and Environment Canada (EC), see page 206.

USA Only

Maintenance, replacement or repair of the emission control devices and systems may be performed by any off-road utility vehicle repair establishment or individual using parts that are “certified” to EPA standards.

Before You Service Your Honda

The Importance of Maintenance	77
Maintenance Safety.....	78
Important Safety Precautions.....	79
Maintenance Schedule	80
Maintenance Record	84

Service Preparations

Maintenance Component Locations	85
Tool Kit	90
Owner's Manual Storage.....	91
Front Hood.....	92
Seat Removal	93
Jack Up Point & Support Point.....	94

(cont'd)