

Instruments *(Continued)*

To reset the tripmeter, average fuel mileage and fuel consumption

- To reset tripmeter A, average fuel mileage, and fuel consumption together, press and hold the **SET** button.

Tripmeter A **Average fuel mileage** **Fuel consumption**



- When they are reset, "0.0" and then "----.-" are displayed at each indication.



- Then, the display returns to the last selected indication.



- To reset tripmeter B, press and hold the **SET** button with tripmeter B displayed.

