


Switches *(Continued)*


NC700XD NC750XD

Parking brake lever and Release button P.55





Hazard switch P.50

Shift up switch (+)

To shift up the gear.  P.66

Headlight dimmer switch

-  : High beam
-  : Low beam

Turn signal switch

- ▶ Pressing the switch turns the turn signal off.

Shift down switch (-)

To shift down the gear.

 P.66