


Lower Cowl

NC750X/XA



Removal

1. Remove the screws.
2. Remove the lower cowl by releasing its prongs from the grommets.

Installation

Install the parts in the reverse order of removal.