


Instruments (Continued)

SP Setting Mode

1 Selecting the user setting mode color:

- 1 Select the SP setting mode. P.36
- 2 Press the SEL button. The color is switched.
 - ▶ When the ECO mode is set to on, AQUA and GREEN can not be selected.
 - ▶ When the shift up mode is set to on, AMBER can not be selected.



3 NC750X

Press the SET button. The user setting mode color is set, and the display moves to the opening/ending display setting.

NC750XA/XD

Press the SET button. The user setting mode color is set, and the display moves to the inputting the opening message.