

Engine

Number	161
Oil	88, 105
Oil Filter	107
Overheats	131
Starting	58
Stop Switch	51, 53, 58, 153
Stopping	153
Will Not Start	130

Environment	160
--------------------------	-----

Equipment

Owner's Manual	73
Tool Kit	73

F

Flooded Engine	59
-----------------------------	----

Fuel

Recommended	70
Tank Capacity	70

Fuses	87, 148
--------------------	---------

G

Gasohol	167
----------------------	-----

Gasoline	69
-----------------------	----

H

Hazard Switch	50, 52
----------------------------	--------

Headlight	146
------------------------	-----

Headlight Aim	127
----------------------------	-----

Headlight Dimmer Switch	50, 52
--------------------------------------	--------

Helmet Holder	74
----------------------------	----

High Beam Indicator	48
----------------------------------	----

High Coolant Temperature Indicator	48
---	----

Honda Contacts	171
-----------------------------	-----

Horn Button	50, 52
--------------------------	--------

I

Ignition Cut-off System

Banking Sensor	154
----------------------	-----

Side Stand	116
------------------	-----

Ignition Key	152
---------------------------	-----

Ignition Switch	51, 58, 153
------------------------------	-------------

Indicators	48
-------------------------	----

Information Record	177
---------------------------------	-----

Instruments	22
--------------------------	----

Instruments, Controls, & Other

Features	153
----------------	-----