


Instruments *(Continued)*

Tachometer color information

Depending on the selected mode, the information of the riding conditions shows by changing the tachometer segment color.



Tachometer segments

The tachometer color information modes:

Base color mode

- User setting mode
- Gear position mode
- DCT mode
- Engine rev mode

NC750XD

ECO mode

Shift up mode

When the user setting mode or DCT mode (NC750XD) in the base color mode is set, the ECO mode and/or shift up mode can be used at the same time.

Order of priority for the color:

Shift up mode

>

ECO mode

>

Base color mode

- User setting mode
- DCT mode NC750XD