

## Maintenance Fundamentals

Have your tires replaced by your dealer.  
For recommended tires and air pressure, see  
"Specifications." ➡ P. 122

Follow these guidelines whenever you replace  
tires.

- Use the recommended tires or equivalents  
of the same size, construction, speed rating,  
and load range.
- Do not install a tube inside a tubeless tire on  
this vehicle. Excessive heat build-up can  
cause the tube to burst.
- Use only tubeless tires on this vehicle.  
The rims are designed for tubeless tires, and  
during hard acceleration or braking, a tube-  
type tire could slip on the rim and cause the  
tire to rapidly deflate.

### **WARNING**

Installing improper tires on your vehicle  
can adversely affect handling and  
stability, and can cause a crash in which  
you can be seriously hurt or killed.

Always use the size and type of tires  
recommended in this owner's manual.