## **Indicators & Displays**

## **Digital Clock**

The digital clock shows the hour and minutes with the 12-hour clock display.

## To set the time:

- 1. Turn the ignition switch to ON(q).
- 2. Change the hourmeter display (page 25).
- 3. Press and hold the SEL/SET switch. The clock will start blinking.
- 4. Press and hold the SEL/SET switch until the desired time appears.
- 5. To complete setting the clock, press the SEL/SET switch, or turn the ignition switch OFF (w).

