

# Servicing Your Honda

---

Air Cleaner Outer Cover Removal .....	128
Rear Mudguard Lid Removal .....	129
Clip Removal .....	130
Jack Up Point & Support Point .....	132

## *Service Procedures*

### Fluids, Filters & Lubricants

Fuel .....	133
Engine Oil & Filters .....	136
Front Final Gear Oil .....	152
Rear Final Gear Oil .....	154
Coolant .....	156
Air Cleaner .....	160
Lubrication .....	164

### Engine

Accelerator Pedal .....	169
Spark Plugs .....	171
Spark Arrester .....	174
Exhaust System .....	176

### Chassis

Suspension .....	177
Frame .....	180
Brakes .....	181
Tires .....	187
Wheels .....	195
Driveshaft Boots .....	196

### Electrical

Battery .....	197
---------------	-----

Appearance Care .....	202
-----------------------	-----