


# Maintenance Component Locations

---

front suspension damping adjuster  
(SXS1000M3L/M5L only) (page 193)

coolant reserve tank  
(page 169)



sub-transmission oil drain bolt  
(page 163)

driveshaft boots  
(page 211)