

# Basic Operation

---

## Operating Launch Mode (SXS1000S4D)

Launch Mode allows the DCT start clutch to be engaged from a high engine speed which increases vehicle acceleration.

### **3 WARNING**

Only use Launch Mode on flat ground, with a clear path in front and sides of your vehicle.

Do not use Launch Mode when carrying cargo, on slippery surfaces or when the vehicle is not on flat ground.

Failure to follow the Launch Mode guidelines can lead to crash in which you or others can be seriously hurt or killed.

Do not use Launch Mode as follows:

- at location where there may be hidden obstacles or there is not a clear sight line
- on slippery surface such as concrete, mud, water and ice
- when carrying cargo
- for any objective other than takeoff

#### To Operate Launch Mode

1. Stop the vehicle completely.
2. Make sure all doors and all side nets are securely closed (page 51, 53).
3. Fasten your seat belt. Check to make sure all passengers fasten their seat belts (page 59) and are holding the handholds firmly (page 64).