



# Quick Reference

---

These symbols are used in Driver Controls section:

<b>SYMBOL</b>	<b>COMPONENT</b>	<b>SEE PAGE</b>
p	START — ignition switch	38
q	ON — ignition switch	38
w	OFF — ignition switch	38
i	Low beam — headlight switch	39
u	High beam — headlight switch	39
P, R, N, H, L	Park — Reverse — Neutral — High — Low — shift select lever	40
	ON — Hill Start Assist (HSA) switch	45
	FLV switch (SXS1000S4D only)	47
+	Up — right shift paddle	48
-	Down — left shift paddle	48