

Servicing Your Honda

Center Rear Panel Removal	108
Clip Removal	109
Jack Up Point & Support Point	110

Service Procedures

Fluids, Filters & Lubricants

Fuel	111
Engine Oil & Filter	114
Front Final Gear Oil.....	124
Rear Final Gear Oil.....	126
Coolant	128
Air Cleaner	133
Lubrication	138

Engine

Accelerator Pedal.....	141
Reverse Inhibitor System	143
Spark Plug	145
Spark Arrester	148
Exhaust System.....	149

Chassis

Suspension	150
Brakes	154
Tires	161
Wheels	168
Driveshaft Boots	169

Electrical

Battery	170
Appearance Care.....	175