

Engine Oil & Filter

Add Engine Oil:

17. Reinstall the drain plug with a new sealing washer, and tighten the drain plug to the specified torque:
18 lbf·ft (25 N·m, 2.5 kgf·m)
18. Lower your Honda SXS safely.
19. Fill the crankcase with the recommended oil, approximately:
3.2 US qt (3.0 ℓ)
20. Reinstall the oil filler cap/dipstick.
21. Reinstall the rubber dust cover.
22. Reinstall the seat bottom.
23. Start the engine and let it idle for 3 – 5 minutes.
24. Remove the seat bottom and fold open the rubber dust cover.
25. Stop the engine and after 2 – 3 minutes, check the oil level. Make sure the oil is between the upper and lower level marks on the dipstick. If necessary, add more oil but do not overfill.
26. Reinstall the oil filler cap/dipstick and rubber dust cover.
27. Reinstall the seat bottom.
28. Check that there are no oil leaks.

If a torque wrench is not used for installation, see your dealer as soon as possible to verify proper assembly.