

# Quick Reference

---

These symbols are used in Driver Controls section:

<b>SYMBOL</b>	<b>COMPONENT</b>	<b>SEE PAGE</b>
p	START — ignition switch	33
q	ON — ignition switch	33
w	OFF — ignition switch	33
t	OFF — headlight switch	34
y	ON — headlight switch	34
D, N, R	Drive — Neutral — Reverse — shift select lever	37
+	Up — right shift paddle	36
-	Down — left shift paddle	36