











Quick Reference

These symbols are used in Controls & Features section:

| SYMBOL | COMPONENT | SEE PAGE |
|---|---|-----------------|
| I | ON — ignition switch | 34 |
| O | OFF — ignition switch | 34 |
|  | 2WD/4WD select lever | 35 |
|  | START button | 36 |
|  | RUN — engine stop switch | 36 |
|  | OFF — engine stop switch | 36 |
|  | ON — headlight switch | 37 |
| • | OFF — headlight switch | 37 |
|  | HI — headlight dimmer switch | 37 |
|  | LO — headlight dimmer switch | 37 |
| AUTO | automatic shift mode — drive mode select switch | 40 |
| ESP | manual shift mode — drive mode select switch | 40 |
|  | upshift switch — gearshift switch | 41 |
|  | downshift switch — gearshift switch | 41 |
|  | Parking Brake/Reverse Lever (P/R lever): P — parking brake R — riding in reverse | 43 |