

# Index

---

## P

P/R lever .....	43
parking .....	43, 102
passengers, no carrying .....	53
pavement, no riding on .....	67
pinging, engine .....	123
plug, spark .....	155
pre-ride inspection .....	55
problems, unexpected .....	204
propeller shaft boots & yoke joint boot .....	182
protective apparel .....	50
EPS (Electric Power Steering) (TRX420FA6 only) .....	48

## R

rear boot guards .....	181
rear driveshaft boots .....	183
rear final gear oil .....	134
recoil starter (Canada only) .....	38, 78
removal,	
rear fender cover .....	121
seat .....	118
tank cover assembly .....	119
reverse,	
assist cable .....	154
assist lever .....	154
gear, shifting into .....	85
indicator .....	14, 17
riding in .....	85
rider training .....	52