

Servicing Your Honda

| | |
|--------------------|-----|
| Clip Removal | 126 |
|--------------------|-----|

Service Procedures

Fluids & Filters

| | |
|---------------------------|-----|
| Fuel | 127 |
| Engine Oil & Filter..... | 130 |
| Rear Final Gear Oil..... | 138 |
| Front Final Gear Oil..... | 141 |
| Coolant | 143 |
| Air Cleaner | 150 |

Engine

| | |
|----------------------|-----|
| Throttle | 156 |
| Spark Plug | 158 |
| Valves..... | 161 |
| Spark Arrester | 162 |

Chassis

| | |
|-----------------------|-----|
| Suspension | 163 |
| Brakes | 166 |
| Tires | 175 |
| Guards | 182 |
| Drivetrain Boots..... | 185 |

Electrical

| | |
|---------------|-----|
| Battery | 187 |
|---------------|-----|

| | |
|----------------------|-----|
| Appearance Care..... | 192 |
|----------------------|-----|