

Index

| | |
|--|--------|
| shifting gears | 65 |
| skid plate | 161 |
| skidding or sliding | 74 |
| spark arrester | 139 |
| spark knock | 102 |
| spark plug | 135 |
| specifications..... | 212 |
| speedometer | 17, 18 |
| stalling on a hill | 77 |
| start button..... | 27 |
| starting, | |
| engine | 60 |
| troubleshooting..... | 188 |
| stop switch, engine | 27 |
| stopping engine | 64 |
| storage, | |
| ATV | 180 |
| owner's manual | 99 |
| suspension, | |
| adjustment (Except TRX420TE)..... | 140 |
| spring pre-load (Except TRX420TE)..... | 141 |
| switch, | |
| downshift | 30, 65 |
| engine stop | 27 |
| headlight..... | 28 |
| headlight dimmer | 28 |
| ignition | 25 |
| upshift | 30, 65 |