

# Index

---

## I

identification, vehicle .....	226
ignition switch .....	34
indicators,	
4WD indicator .....	14, 18, 23
fuel warning indicator .....	14, 17
gear position indicator .....	24
high coolant temperature indicator .....	14, 17, 213
maintenance minder indicator .....	32
neutral indicator .....	14, 17
PGM-FI indicator .....	17
PS (Electric Power Steering) indicator (TRX420FM2 only) .....	17
reverse indicator .....	17
inspection, pre-ride .....	55

## K

key,	
lost .....	221
number .....	221
kit, tool .....	112

## L

labels, safety .....	5
lamp check .....	15
lever,	
2WD/4WD .....	35
limit, weight .....	60
load limits .....	60
loading guidelines .....	61
lubrication,	
engine oil .....	122
front final gear oil .....	134
rear final gear oil .....	131