

The indicators and displays on your ATV keep you informed, alert you to possible problems, and make your riding safer and more enjoyable. Refer to the indicators frequently. Their functions are described on the following pages.

(TRX420TM/FM)



(TRX420FPM)



- (1) reverse indicator
- (2) neutral indicator
- (3) PS (Electric Power Steering) indicator (TRX420FPM only)
- (4) 4WD indicator (Except TRX420TM)
- (5) high coolant temperature indicator
- (6) PGM-FI indicator
- (7) multi-function display (TRX420FPM only)
- (8) hourmeter/odometer/ tripmeter select button (TRX420FPM only)