
Controls & Features

Reverse Selector Knob

The reverse selector knob (1), located on the rear brake lever/parking brake lever (2), is used to shift into reverse. To operate, with your ATV stopped and the transmission in neutral (TRX420TM, TRX420FM : make sure the neutral indicator lights, TRX420FPM: make sure the gear position indicator shows "N"), push in the knob, squeeze the rear brake lever/parking brake lever, then depress the shift lever. See *Riding in Reverse*, page 67.

LEFT HANDLEBAR



- (1) reverse selector knob
- (2) rear brake lever/parking brake lever