


# Tires

Also, if you hit a pothole or other hard object while riding, stop as soon as you safely can and carefully inspect the tires for damage.

## Tread Wear

FRONT

REAR



(1) groove depth  
(2) wear indicator

(3) wear indicator location mark

To check the condition of a tire tread, measure the groove depth (1) in the center of the tire, or check the wear indicator (2).

For best performance, you should replace a tire before the tread depth at the center reaches the following limits:

|       |                |
|-------|----------------|
| front | 3/16 in (4 mm) |
| rear  | 3/16 in (4 mm) |