

Servicing Your Honda

Tank Cover Assembly Removal	132
Clip Removal	133

Service Procedures

Fluids & Filters

Fuel	134
Engine Oil & Filter	137
Rear Final Gear Oil	146
Front Final Gear Oil	149
Coolant	151
Air Cleaner	159

Engine

Throttle	165
Reverse Inhibitor System	167
Spark Plug	168
Valves	171
Spark Arrester	172

Chassis

Suspension	173
Brakes	176
Tires	185
Guards	192
Drivetrain Boots	193

Electrical

Battery	194
Appearance Care	199