

GPS Mode

To Change the Coordinates for an Existing Waypoint Number:

Follow steps 1 – 4 under *Advance Waypoint Selection* (page 73) and ‘‘overwrite’’ your previous waypoint.

To Delete the Coordinates for an Existing Waypoint Number:

1. Follow steps 1 – 4 under *Advance Waypoint Selection* (page 73).
2. Within 5 seconds, press and hold the plus button and minus button for about 2 seconds. The waypoint will delete.

To Delete the Coordinates for all Existing Waypoint Number:

1. Follow steps 1 , 2 and 4 under *Advance Waypoint Selection* (page 73).
2. Within 5 seconds, press and hold GPS/WP button, plus button and minus button for about 2 seconds. The waypoints will delete.