

B

| | |
|-------------------------------------|----------------|
| battery | 176 |
| brake light switch adjustment | 165 |
| brakes, | |
| cables | 164 |
| draining water from | 166 |
| fluid | 156 |
| front brake lever | 39 |
| pad wear | 159 |
| parking | 40 |
| rear brake lever | 39 |
| rear brake lever freeplay | 162 |
| rear brake pedal | 39 |
| rear brake pedal freeplay | 160 |
| shoe wear | 164 |
| braking | 85 |
| break-in guidelines | 226 |
| button, | |
| adjust | 14, 18, 25 |
| hour select | 14, 18 |
| minute select | 14, 18, 25 |
| odometer/tripmeter select | 14, 17, 22, 23 |
| RESET | 14, 17, 22, 23 |