

# Index

---

stalling on a hill .....	95
start/over ride button .....	39
starting,	
engine .....	78
troubleshooting .....	212
stop switch, engine .....	40
stopping engine .....	82
storage,	
ATV .....	204
owner's manual .....	119
suspension,	
adjustment .....	164
spring pre-load .....	165
switch,	
4WD .....	35
differential lock .....	36
engine stop .....	40
headlight .....	41
headlight dimmer .....	41
ignition .....	34
<b>T</b>	
tank cover assembly removal .....	122
throttle,	
cable .....	155, 156
lever .....	43, 155, 156
tires,	
air pressure .....	179
flat .....	215
repairing .....	183
replacing .....	184
thread conditions .....	181, 182
tool kit .....	118