

Indicators & Displays

7	Mode select button	Selects display in the lower parts of multi-function display. Adjusts the digital clock (page 26). Changes the speed and mileage units (page 22). Resets the tripmeter to zero (0) (page 27). This button also used to reset the maintenance tripmeter and maintenance hourmeter (page 33).
---	--------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------