
Maintenance Component Locations



rear brake lever/ parking brake lever

throttle lever