

Owner's Manual Storage


Your ATV provides storage for the owner's manual so you'll have it with you for easy reference. Store your owner's manual (1) in the plastic document bag (2) underside of the rear fender cover (3).

The owner's manual, air pressure gauge (4) and 40 A spare fuse (5) should be stored in the plastic document bag and fastened with the rubber band (6).

To remove the rear fender cover, see page 121.

Be careful not to flood this area when washing your ATV.

REAR FENDER COVER UNDERSIDE



(1) owner's manual
(2) plastic document bag
(3) rear fender cover

(4) air pressure gauge
(5) 40 A spare fuse
(6) rubber band