
Brakes

REAR



Check the wear indicator. If the wear indicator (3) aligns with the reference mark (4), replace both pads as a set, see your Honda dealer for this service.