

Storing Your Honda

Removal from Storage

Refer to *Safety Precautions* on [page 99](#).

1. Uncover and clean your ATV.
2. If your ATV has been stored for more than four months – change the engine oil ([page 119](#)).
3. If your ATV has been stored for more than two months – ask your dealer to drain and replace the fuel.
4. Charge the battery ([page 166](#)) as required. Install the battery.
5. Perform a pre-ride inspection ([page 49](#)), then test-ride your ATV at low speeds.