

Indicator & Controls

This section shows the location of the indicator and all controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Operation Component Locations	14
Indicator	17
Neutral Indicator Lamp	17
Controls & Features	18
Fuel Valve	18
Choke Lever	19
Ignition Switch.....	20
Start Button.....	21
Engine Stop Switch.....	22
Throttle Lever	23
Front Brake Lever.....	24
Rear Brake Lever/Parking Brake Lever	24
Rear Brake Pedal.....	25
Parking Brake	26
Flag Pole Bracket	27