

Engine

Number	137
Oil	71, 81
Oil Filter	83
Overheats	108
Starting	45
Stop Switch	32, 37, 45, 46, 130
Stopping	130
Will Not Start	107

Environment	136
--------------------------	-----

Equipment

Accessory Socket	57
Owner's Manual	58, 130

F

Final Drive Oil	72
------------------------------	----

Flooded Engine	45
-----------------------------	----

Fuel

Gauge	21
Oxygenated	144
Recommended	56
Remaining	21
Tank Capacity	56

Fuses	70, 125
--------------------	---------

G

Gasohol	144
----------------------	-----

Gasoline	56
-----------------------	----

H

Haedlight Dimmer Switch	36
--------------------------------------	----

Handle Grip Heater	40
---------------------------------	----

Hazard Switch	32, 36
----------------------------	--------

Headlight Aim	98
----------------------------	----

Headlight Dimmer Switch	32
--------------------------------------	----

Helmet Holder	58
----------------------------	----

High Beam Indicator	31
----------------------------------	----

High Coolant Temperature Indicator	30, 108
---	---------

Honda Contacts	148
-----------------------------	-----

Horn Button	32, 36
--------------------------	--------

I**Ignition Cut-off System**

Banking Sensor	130
----------------------	-----

Side Stand	94
------------------	----

Ignition Key	129
---------------------------	-----

Ignition Switch	33, 37, 45, 46, 130
------------------------------	---------------------

Indicators	30
-------------------------	----