

2. Open the fuel fill cap.
3. Add fuel until the level reaches the bottom of the fill neck (3). Avoid overfilling the tank. There should be no fuel in the fill neck.

### **WARNING**

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

4. After refueling, align the latch in the cap with the slot in the fill neck. Push the cap into the fill neck until it snaps and locks.
5. Remove the ignition key from the cap.