

# Troubleshooting

**Engine Will Not Start** .....P. 79

**Overheating (High coolant temperature indicator is on)**.....P. 80

**Warning Indicators On or Flashing** .....P. 81

Low Oil Pressure Indicator.....P. 81

PGM-FI (Programmed Fuel Injection)

Malfunction Indicator Lamp (MIL) .....P. 81

ABS (Anti-lock Brake System) Indicator

(VT1300CXA only) .....P. 82

**Tire Puncture** .....P. 83

Emergency Repair Using a Tire Repair Kit ...P. 83

Removing Wheels.....P. 83

**Electrical Trouble** ..... P. 91

Battery Goes Dead ..... P. 91

Burned-out Light Bulb..... P. 91

Blown Fuse ..... P. 95