


Model equipped with Optional Passenger Seat Kit



Removal

1. Remove the bolt A and collar A.
2. Remove the seat strap by removing the bolts B, washers and collars B.
3. Remove the rear seat.
4. Remove the bolts C.
5. Pull the front seat back and up.