


Inspecting the Brake Pads

Check the condition of the brake pad wear indicators.

Front The pads need to be replaced if a brake pad is worn to the indicator.



Front Inspect the brake pads from the bottom of the brake caliper.

If necessary have the pads replaced by your dealer.

Always replace both left and right brake pads at the same time.