

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.

Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 32	<b>Clutch</b> .....	P. 72
<b>Maintenance Schedule</b> .....	P. 34	<b>Throttle</b> .....	P. 75
<b>Maintenance Fundamentals</b> .....	P. 37	<b>Crankcase Breather</b> .....	P. 76
<b>Removing &amp; Installing Body Components</b> ..	P. 50	<b>Other Adjustments</b> .....	P. 77
Battery .....	P. 50	Adjusting the Headlight Aim .....	P. 77
Seat .....	P. 51	Adjusting the Rear Suspension .....	P. 78
Side Cover .....	P. 52		
<b>Spark Plug</b> .....	P. 53		
<b>Engine Oil</b> .....	P. 55		
<b>Air Cleaner</b> .....	P. 59		
<b>Coolant</b> .....	P. 60		
<b>Final Drive Oil</b> .....	P. 62		
<b>Brakes</b> .....	P. 64		
<b>Side Stand</b> .....	P. 71		