

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional larger tool kit may be available. Check with your Honda dealer’s parts department.

<b>Importance of Maintenance</b> .....	P. 32	<b>Final Drive Oil</b> .....	P. 70
<b>Maintenance Schedule</b> .....	P. 34	<b>Air Cleaner</b> .....	P. 72
<b>Maintenance Fundamentals</b> .....	P. 37	<b>Crankcase Breather</b> .....	P. 73
<b>Removing &amp; Installing Body Components</b> ...	P. 49	<b>Throttle</b> .....	P. 74
Seat .....	P. 49	<b>Other Adjustments</b> .....	P. 75
Side Cover .....	P. 50	Rear Suspension .....	P. 75
Battery .....	P. 51	Headlight Aim .....	P. 76
<b>Spark Plug</b> .....	P. 52	Brake Light Switch .....	P. 76
<b>Engine Oil</b> .....	P. 54		
<b>Coolant</b> .....	P. 58		
<b>Brakes/Clutch</b> .....	P. 60		
<b>Side Stand</b> .....	P. 69		