

## Storage Compartment

---

(VT750C)


The storage compartment (1) is located behind the left side cover (page 75 ).

The tool kit (2) should be stored in the storage compartment.

To open the storage compartment, remove the left side cover (page 75 ). Insert the ignition key (3) and turn it 90 degrees counterclockwise. Open the storage compartment lid (4).

To close the storage compartment, close the storage compartment lid. Turn the ignition key 90 degrees clockwise and remove it. Install the left side cover (page 75 ).

LEFT SIDE



- (1) storage compartment
- (2) tool kit
- (3) ignition key
- (4) storage compartment lid