


## Brakes ► Adjusting the Rear Brake Pedal Freeplay

3. Push the brake arm to confirm that there is a gap between the rear brake adjusting nut and brake arm pin.



After adjustment, confirm the freeplay of the brake pedal.

Make sure the brake rod, brake arm, spring and fastener are in good condition.

### NOTICE

Do not turn the adjuster beyond its natural limits.