

Refueling

Fuel type: Unleaded gasoline only

Recommended fuel octane number: Your scooter is designed to use Pump Octane Number (PON) 86 or higher.

Tank capacity: 2.11 US gal (8.0 liters)

Refueling and Fuel Guidelines (P13)

Opening the Fuel Fill Cap

- a Insert the ignition key and turn it to the position of SEAT FUEL.
- b Push the FUEL side of the fuel lid and seat opener switch.
▶ The fuel lid opens.

