

## Clock (12-hour display) To set the clock: P.22

**Fuel gauge**Remaining fuel when there is only 1st (E) segment: 0.29 US gal (1.1 L) This segment flashes when the fuel decreases further.



If the fuel gauge indicator flashes in a repeat pattern or turns off: P.85