



Instruments *(Continued)*

To set the clock:

- 1 Turn the ignition switch to the ON position.
- 2 With odometer displayed, press and hold the mode switch until the clock digits start flashing.



- 3 Press the mode switch until the desired time is displayed.
 - ▶ The time is advanced by one minute, each time the switch is pressed.
 - ▶ The time is advanced by ten minutes, when the switch is pressed and held.



- 4 Wait for 5 seconds and press the mode switch. The clock is set.
 - ▶ The time can also be set by turning the ignition switch to the OFF position.