

Refueling

Fuel type: Unleaded gasoline only

Recommended fuel octane number:
Pump Octane Number (PON) 86 or higher.

Tank capacity: 2.11 US gal (8.0 L)

Refueling and Fuel Guidelines ➔ P.13

Opening the Fuel Fill Cap

- 1 Insert the ignition key and turn it to the position of SEAT FUEL.
- 2 Push the FUEL side of the fuel lid and seat opener switch.
 - ▶ The fuel lid opens.

