

Operation

Press the answer back button on the Honda SMART Key.

- ▶ The answer back system will not function when the ignition switch is **I** (On) position.

If the ignition switch is left the **O** (Off) or **i** (Lock) position for more than 10 days, the answer back system will no longer operate. During the system is activating, when the scooter receives a signal by pressing the answer back button or alarm button, the system activation will be extended for 10 days. To reset the system, unlock the ignition switch and turn the ignition switch **I** (On) position once.

- ▶ To unlock the ignition switch. **➡P.32**

NOTICE

When the battery in the scooter is weak, the answer back system may not function.

Adjusting the Answer Back Buzzer Sound Volume Level


You can select 3 buzzer sound volume levels.

- 1 Make sure that the Honda SMART Key system is activated. **➡P.28**
- 2 Remove the battery cover. **➡P.77**
- 3 Push the ignition switch to authenticate the Honda SMART Key system. **➡P.32**
- 4 Connect the EM mode coupler provided in the tool kit to the EM mode connector.

➡P.111

- ▶ The Honda SMART Key indicator and ignition switch ring go off.

Answer back button



Ignition switch

